

Punch Press Automation

PressCam 8

REPLACEMENT PARTS LISTING

Part Number	Description
11-131	Panel Mount (with gasket)
11-132	LCD mounting bracket (blue)
11-133	Aluminum Shield cover for computer board
11-134	Metal Box enclosure (with gasket)
11-135	Solid State Relay hold-down for I/O board
11-159	Large Metal Box enclosure (includes space for TTLM module)
18-005	B/W LCD display panel (with backlight)
18-006	LCD Backlight power supply
18-007	LCD Backlight fluorescent tube
20-022	1A Slo-Blo nano SMF fuse
20-023	5A Fuse (white nano)
21-047	Tuning Knob (black knob)
21-048	Tuning Knob (black ring)
26-071	Graphic overlay skin
30-009	Replacement Tonnage Controller (3 or 4 channel input unit)
30-010	Replacement Tonnage Sensors & 35' of cable
30-013	Replacement Tonnage Controller (1 or 2 channel input unit)
32-038	Output Module (Solid State AC)
32-039	Output Module (Solid State DC)
32-041	Output Relay (G2R-1-S)
32-101	4 pole 12 VDC (clear KACO safety relay)
35-065	EEPROM JOB memory chip (50 jobs) (2 chips are required for 100 jobs) (2 chips are required for 100 jobs)
39-051	RUN/PROG Keyswitch (with keys and cable)
40-002	Tuning Encoder device
45-019	LCD cable (from LCD to Computer board)
45-020	Resolver cable (30') with connectors
52-115	Power & I/O board (without output modules) specify solid-state or relay
52-116	Dual Computer board (with 100 job memory)
52-122	I/O ribbon cable (from I/O board to Computer board) 2'
52-123	Power cable (from I/O board to Computer board) 2'
52-227	Resolver unit (no cable) (formerly 40-003)
52-282	Serial to Ethernet Board for PressCam 8